

## A-Core Container

# Energy storage liquid cooling host and compressor



## Overview

---

The liquid-cooled host uses compressor power to open the refrigerant circulation loop. The refrigerant is throttled and decompressed through the electronic expansion valve, and enters the liquid-cooling plate to contact the battery core for heat exchange, thereby achieving battery pack cooling.

## Energy storage liquid cooling host and compressor

---

### Contact Us

---

For catalog requests, pricing, or partnerships, please visit:  
<https://www.a-core.pl>